

## **INSTALLATION INSTRUCTIONS**

The CUFVC Vent Cover is designed to seal the typical 8"x16" foundation vent, and can be easily installed using your choice of screws and anchors (Tapcon type) and/or construction adhesive.

In addition using an application of silicon caulking in conjunction with your anchors will help create a weather tight seal.

### **NOTE:**

If installing from the front it may be necessary to remove the existing vent and install the cover or trim the insulation so that the cover may fit over the existing vent.